



#### Key Parameters:

/E = 2 Enable ambient probe S1 on external display  
 St = Setpoint  
 rd = Differential  
 F2 = 0 Fans cycle with compressor (0=no, 1=yes)

#### Parts Required:

DN33C0HR00 Din rail mount controller  
 IR00XGD000 Remote display  
 PSTCON01B0 Connecting cable  
 IROPZSER30 Remote display interface